

ArtMolds Vacuum Chamber Assembly Instructions

The vacuum chamber is complete. All you need for assembly is an adjustable wrench and of course a vacuum pump to supply your vacuum. Complete instructions for operating the vacuum chamber are contained in the ArtMolds Vacuum Chamber Operating Manual.



The vacuum chamber arrives in compact box.



Check the contents against the list in the operating manual



Install the valve, nipple and gauge onto the cross fitting.



Thread the nipple end of the fitting into the chamber,



Remove the protective sheets from both acrylic plates.



Center one gasket on one acrylic plate.



Center the chamber body on the gasket.



Center the top gasket and acrylic plate on the top.



Connect the hose to your vacuum pump.