

MOLDEZ™ MOLD RELEASE

NONTOXIC –SAFE FOR PROLONGED BODY CONTACT

DESCRIPTION: MoldEZ is a skin and hair cream made with cholesterol, jojoba oil, aloe vera and collagen protein and is completely water-soluble. When applied to body hair it acts as a release in the lifecasting process so that the MoldGel does not hold hair. Hair that is imbedded in MoldGel will slip out with a slight even pull. When MoldEZ is applied to the MoldGel mold, it fills pinholes and acts as a release for the CastRite casting system.

FEATURES:

- Washes out with water
- Safe for skin and MoldGel molds
- Fills pin holds
- An adhesive for mother mold and MoldGel
- Acts as a release in MoldGel molds
- Better than Vaseline

MODEL PREPARATION: MoldEZ should be applied to all body hair. It should be liberally and thickly applied into the pubic and underarm hair – not just on the surface, but also **down to the roots**. After application, the hair can then be combed back into a natural shape for molding. When molding is complete, the model can easily remove the application of MoldEZ by showering. Unlike Vaseline that may take many types of washing to remove, MoldEZ washes out the first time in ordinary water. **NOTE:** When casting the head there is a tendency for hair in the front and the very back of the head to get caught in the MoldGel. Prior to application of MoldGel make a second application of MoldEZ to these areas.

DEMOLD: When removing the mold from the model, no matter how careful your MoldEZ application, some long hair will be entrapped by some MoldGel or bandages. Anticipate this so that as you de-mold. For a torso remove the mold from the neck first moving toward the groin. Then slowly tip the mold forward. Any trapped hairs will be released by a slow, even pull on the mold. Be careful, as too much of a pull will result in ripping your mold and/or pulling out hair. For a head, reach under the mold with your hand to help pull out any trapped hairs.

PREPPING THE MOLD FOR CASTING. Clean out your mold. If the MoldGel is separating from the bandage cast, use a dollop of MoldEZ as an adhesive (Larger separations call for a spring-loaded clothes pin.) Then using the tips of your fingers, apply a finger full of MoldEZ to the surface of the mold. Move your finger tips in a slow circular motion so that you can feel for imperfections. Fill any pins hole with the MoldEZ as you go. Add additional MoldEZ so that you coat the entire mold twice. You may use Crisco to liberally coat the edges of the mold to extend the amount of MoldEZ.

SAFETY AND CLEANUP: MoldEZ is safe for skin and hair. It is not for human consumption. It easily showers away or washes off in tap water.

DISCLAIMER: The information in this bulletin and otherwise provided by ArtMolds is considered accurate. However, no warranty is expressed or implied regarding the accuracy of this date, the results to be obtained by the use thereof, or that any such use will not infringe any patent. The user assumes all risk and liability whatsoever in connection therewith.